



*Application
and
Maintenance
Guide*



www.TimberProCoatings.com

Deck Application

Deck and Fence Formula:

If the wood surface is previously finished or weathered and discolored, the surface must either be sanded (smooth wood only) or chemically stripped with Timber Pro Strip & Brite, and then power washed to restore the surface to new wood condition. See more complete Strip & Brite directions. All new decks must be sanded 60-80 grit.

Decks can be one of the most problematic areas to coat if all preparation and application instructions are not followed completely.

- a) Apply a flood coat of Timber Pro Deck & Fence Formula and smooth out any runs, puddles and drips.
- b) Allow to dry 16 hours (this will vary with temperature and humidity level).
- c) Apply a second and final colour coat.
- d) Let dry 16 hours before heavy foot traffic.

Note: If possible, coat all sides of the boards and coat the end grains heavily to reduce moisture uptake. In cases of low, unventilated decks or decks exposed to constant moisture, apply only one coat of the Timber Pro Deck & Fence Formula and then re-treat as needed.





Timber Pro Coatings Canada

Unit 130-6251 Graybar Road
Richmond, BC, Canada V6W 1H3

Toll Free: 1-877-666-4244

Tel: (604) 270-4244

Email: canadainfo@timberprocoatings.com

06/2012

www.TimberProCoatings.com